

# INSTRUCTIONS - PARTS LIST



ALUMINUM, STAINLESS STEEL, AND CAST IRON

## VERDERAIR VA 50

# Air-Operated Diaphragm Pumps

819.4273

Rev. ZAK  
EN

*For fluid transfer applications. For professional use only.*

8.4 bar Maximum Fluid Working Pressure

8.4 bar Maximum Air Input Pressure



### Important Safety Instructions


Read all warnings and instructions in this manual. Save these instructions.

Patent No.

CN ZL94102643.4 FR 9408894


JA 3517270

US 5,368,452



03940B

**Aluminum Model with  
End Flange**



ti36735a

**Stainless Steel Model with  
Center Flange**



Ex h IIC 66°C...135°C Gb  
Ex h IIIC T135°C Db

## Table of Contents

<b>Table of Contents</b> .....	<b>2</b>	<b>Repair Kit Listing</b> .....	<b>23</b>
<b>Configuration Number Matrix</b> .....	<b>3</b>	<b>Parts</b> .....	<b>25</b>
<b>Symbols</b> .....	<b>4</b>	<b>Torque Sequence</b> .....	<b>29</b>
<b>Installation</b> .....	<b>6</b>	<b>Dimensions</b> .....	<b>30</b>
<b>Operation</b> .....	<b>11</b>	<b>Technical Data</b> .....	<b>33</b>
<b>Maintenance</b> .....	<b>12</b>	<b>Performance Chart</b> .....	<b>34</b>
<b>Troubleshooting</b> .....	<b>13</b>		
<b>Service</b> .....	<b>14</b>		
Repairing the Air Valve .....	14		
Ball Check Valve Repair .....	16		
Diaphragm Repair .....	17		
Bearing and Air Gasket Removal .....	21		

# Configuration Number Matrix

Check the identification plate (ID) for the 15–digit Configuration Number of your pump. Use the following matrix to define the components of your pump.

Sample Configuration Number: VA50AA – SS TF TF TB 00

<b>VA50</b>	<b>A</b>	<b>A</b>	<b>SS</b>	<b>TF</b>	<b>TF</b>	<b>TB</b>	<b>00</b>
Pump Model	Fluid Section	Air Section	Seat	Checks	Diaphragms	Connections	Options

**NOTE:** Some combinations are not possible. Please check with your local supplier or on [www.verderair.com](http://www.verderair.com).

Pump Model (1 and 2)	Fluid Section Material (3)		Air Section Material (4)		Seats (5)	
VA50	A	Aluminum	A	Aluminum	BN	Buna–N
	I	Cast Iron	S	Stainless Steel	GE	Geolast
	S	Stainless Steel			HY	TPE
					PP	Polypropylene
					SP	Santoprene
					SS	Stainless Steel
					VT	FKM

Balls (6)		Diaphragm (7)		Connections (8)		Options (9)	
AC	Acetal	GE	Geolast	TB	Threaded BSP	00	Standard
BN	Buna–N	HY	Hytrel	TN	Threaded NPT		
GE	Geolast	SP	Santoprene	FC	Center flange		
HS	Hardened Steel	TO	PTFE One-Piece				
HY	TPE	TF	PTFE/Neoprene Two-Piece				
SP	Santoprene	VT	FKM				
TF	PTFE						
VT	FKM						

**ATEX T-code rating is dependent on the temperature of the fluid being pumped. Fluid temperature is limited by the materials of the pump interior wetted parts. See Technical Data for the maximum fluid operating temperature for your specific pump model.**

## Symbols

### Warning Symbol



This symbol alerts you to the possibility of serious injury or death if you do not follow the instructions.

### Caution Symbol



This symbol alerts you to the possibility of damage to or destruction of equipment if you do not follow the instructions.

## Warning



### EQUIPMENT MISUSE HAZARD

Any misuse of the equipment or accessories, such as overpressurizing, modifying parts, using incompatible chemicals and fluids, or using worn or damaged parts, can cause them to rupture and result in splashing in the eyes or on the skin, other serious injury, or fire, explosion, or property damage.

- This equipment is for professional use only. Observe all warnings. Read and understand all instruction manuals, warning labels, and tags before operating the equipment.
- Never alter or modify any part of this equipment; doing so could cause it to malfunction.
- Check all equipment regularly and repair or replace worn or damaged parts immediately.
- Never exceed the recommended working pressure or the maximum air inlet pressure stated on your pump or in the on page 32.
- Do not exceed the maximum working pressure of the lowest rated component in your system. This equipment has an **8.3 bar maximum working pressure at 8.3 bar maximum incoming air pressure.**
- Be sure that all fluids and solvents used are chemically compatible with the wetted parts shown in the on page 32. Always read the manufacturer's literature before using fluid or solvent in the pump.
- Never move or lift a pump under pressure. If dropped, the fluid section may rupture. Always follow the **Pressure Relief Procedure** on page 11 before moving or lifting the pump. The pump is very heavy. If it must be moved, have two people lift the pump by grasping the outlet manifold securely.


**WARNING**
**HAZARDOUS FLUIDS**


Improper handling of hazardous fluids or inhaling toxic vapors can cause extremely serious injury, even death, due to splashing in the eyes, ingestion, or bodily contamination. Observe all the following precautions when handling known or potentially hazardous fluids.



- Know what fluid you are pumping and its specific hazards. Take precautions to avoid a toxic fluid spill.
- Always wear appropriate clothing and equipment, such as eye protection and breathing apparatus, to protect yourself.
- Store hazardous fluid in an appropriate, approved container. Dispose of it according to all local, state and federal guidelines for hazardous fluids.
- Secure the fluid outlet hose tightly into the receiving container to prevent it from coming loose and improperly draining the fluid.
- Pipe and dispose of the exhaust air safely, away from people, animals, and food handling areas. If the diaphragm fails, the fluid is exhausted along with the air. See **Air Exhaust Ventilation** on page 10.

**FIRE AND EXPLOSION HAZARD**


Static electricity is created by the flow of fluid through the pump and hose. If the equipment is not properly grounded, sparking may occur. Sparks can ignite fumes from solvents and the fluid being pumped, dust particles and other flammable substances, whether you are pumping indoors or outdoors, and can cause a fire or explosion and serious injury and property damage.



- To reduce the risk of static sparking, ground the pump and all other equipment used or located in the work area. Check your local electrical code for detailed grounding instructions for your area and type of equipment. Refer to **Grounding** on page 6.
- If you experience any static sparking or even a slight shock while using this equipment, **stop pumping immediately**. Check the entire system for proper grounding. Do not use the system again until the problem has been identified and corrected.
- Pipe and dispose of the exhaust air safely, away from all sources of ignition. If the diaphragm fails, the fluid is exhausted along with the air. See **Air Exhaust Ventilation** on page 10.
- Do not smoke in the work area. Do not operate the equipment near a source of ignition or an open flame, such as a pilot light.

**HALOGENATED HYDROCARBON HAZARD**


Never use 1,1,1-trichloroethane, methylene chloride, other halogenated hydrocarbon solvents or fluids containing such solvents in Aluminum Pumps. Such use could result in a serious chemical reaction, with the possibility of explosion, which could cause death, serious injury, and/or substantial property damage.

Consult your fluid suppliers to ensure that the fluids used are compatible with aluminum parts.

## Installation

### General Information

1. The Typical Installation shown in FIG. 2 is only a guide for selecting and installing system components. Contact your VERDER Customer Service for assistance in planning a system to suit your needs.
2. Always use Genuine VERDER Parts and Accessories.
3. Reference numbers and letters in parentheses refer to the callouts in the figures and the parts lists on pages 25–26.

### Warning

#### HAZARDOUS FLUIDS



To reduce the risk of serious injury, splashing in the eyes or on the skin, and toxic fluid spills, **never** move or lift a pump under pressure. If dropped, the fluid section may rupture. Always follow the **Pressure Relief Procedure** on page 11 before moving or lifting the pump.

4. The pump is very heavy. If it must be moved, have two people lift the pump by grasping the outlet manifold (103) securely. See FIG. 3 on page 9.

### Tightening Screws Before First Use

Before using the pump for the first time, check and retorque all external fasteners. See **Torque Sequence** on page 29. After the first day of operation, retorque the fasteners. Although pump use varies, a general guideline is to retorque fasteners every two months.

### Grounding

### Warning

#### FIRE AND EXPLOSION HAZARD




This pump must be grounded. Before operating the pump, ground the system as explained below. Also, read the section **FIRE AND EXPLOSION HAZARD**, on page 5.



To reduce the risk of static sparking, ground the pump and all other equipment used or located in the pumping area. Check your local electrical code for detailed grounding instructions for your area and type of equipment.

### Ground all of this equipment.

- *Pump:* Connect a ground wire and clamp as shown in FIG. 1. Loosen the grounding screw (W). Insert one end of a 1.5 mm<sup>2</sup> minimum ground wire (Y) behind the grounding screw and tighten the screw securely. Connect the clamp end of the ground wire to a true earth ground. Order Part No. 819.0157 Ground Wire and Clamp.



02646

FIG. 1

- *Air and fluid hoses:* Use only grounded hoses with a maximum of 150 m combined hose length to ensure grounding continuity.
- *Air compressor:* Follow the manufacturer's recommendations.
- *All solvent pails used when flushing,* according to local code. Use only metal pails, which are conductive. Do not place the pail on a non-conductive surface, such as paper or cardboard, which interrupts the grounding continuity.
- *Fluid supply container:* Follow the local code.

# Installation

## Mountings

### Caution

The pump exhaust air may contain contaminants. Ventilate to a remote area if the contaminants could affect your fluid supply. See Air Exhaust Ventilation on page 10.

1. Be sure the mounting surface can support the weight of the pump, hoses, and accessories, as well as the stress caused during operation.
2. For all mountings, be sure the pump is bolted directly to the mounting surface.
3. For ease of operation and service, mount the pump so the air valve cover (2), air inlet, and fluid inlet and outlet ports are easily accessible.
4. Rubber Foot Mounting Kit 819.4332 is available to reduce noise and pump movement during operation.
5. Prolonged exposure to UV radiation will degrade natural polypropylene components of the pumps. To prevent potential injury or equipment damage, do not expose pump or the plastic components to direct sunlight for prolonged periods.

## Air Line

### Warning

A bleed-type master air valve (B) is required in your system to relieve air trapped between this valve and the pump. Trapped air can cause the pump to cycle unexpectedly, which could result in serious injury, including splashing in the eyes or on the skin, injury from moving parts, or contamination from hazardous fluids. See FIG. 2.

1. Install the air line accessories as shown in FIG. 2. Mount these accessories on the wall or on a bracket. Be sure the air line supplying the accessories is grounded.
  - a. Install an air regulator (C) and gauge to control the fluid pressure. The fluid outlet pressure will be the same as the setting of the air regulator.
  - b. Locate one bleed-type master air valve (B) close to the pump and use it to relieve trapped air. See the **Warning** above. Locate the other master air valve (E) upstream from all air line accessories and use it to isolate them during cleaning and repair.

- c. The air line filter (F) removes harmful dirt and moisture from the compressed air supply. Install a grounded, flexible air hose (A) between the accessories and the 1/2 bspt pump air inlet (N). See FIG. 2. Use a minimum 13 mm ID air hose. Screw an air line quick disconnect coupler (D) onto the end of the air hose (A), and screw the mating fitting into the pump air inlet snugly. Do not connect the coupler (D) to the fitting until you are ready to operate the pump.

## Fluid Suction Line

1. **Use grounded fluid hoses (G).** The pump fluid inlet (R) 2 in. bspt on pumps with connection Code 8=TB. The pump fluid inlet is 2 in. npt on pumps with connection Code 8=TN. The inlet and outlet fluid ports have ANSI/DIN flanges. Screw the fluid fitting into the pump inlet securely.
2. If the fluid inlet pressure to the pump is more than 25% of the outlet working pressure, the ball check valves will not close fast enough, resulting in inefficient pump operation.
3. At inlet fluid pressures greater than 1.05 bar, diaphragm life will be shortened.
4. See the on page 32 for maximum suction lift (wet and dry).

## Fluid Outlet Line

### Warning

A fluid drain valve (J) is required to relieve pressure in the hose if it is plugged. The drain valve reduces the risk of serious injury, including splashing in the eyes or on the skin, or contamination from hazardous fluids when relieving pressure. Install the valve close to the pump fluid outlet. See FIG. 2.


1. **Use grounded fluid hoses (L).** The pump fluid outlet (S) is 2 in. bspt on pumps with connection Code 8=TB. The pump fluid outlet is 2 in. npt on pumps with connection Code 8=TN. The inlet and outlet fluid ports have ANSI/DIN flanges. Screw the fluid fitting into the pump outlet securely.
2. Install a fluid drain valve (J) near the fluid outlet. See the **Warning** above.
3. Install a shutoff valve (K) in the fluid outlet line.

## Installation

### FLOOR MOUNT TYPICAL INSTALLATION

#### KEY

- A Air Supply Hose
- B Bleed-Type Master Air Valve (required for pump)
- C Air Regulator
- D Air Line Quick Disconnect
- E Master Air Valve (for accessories)
- F Air Line Filter
- G Fluid Suction Hose
- H Fluid Supply
- J Fluid Drain Valve (required)
- K Fluid Shutoff Valve
- L Fluid Hose
- N 1/2 npt(f) Air Inlet Port
- R\* 2 in. bspt Fluid Inlet Port
- S\* 2 in. bspt Fluid Outlet Port
- Y Ground Wire (required; see page 6 for installation instructions)



03943B

FIG. 2

\* On pumps with connection Code 8=TB=bspt, connection Code 8=TN=npt, and connection Code 8=FC=Flange Center.



# Installation

## Changing the Orientation of the Fluid Inlet and Outlet Ports

The pump is shipped with the fluid inlet (R) and outlet (S) ports facing the same direction. See FIG. 3. To change the orientation of the inlet and/or outlet port:

1. Remove the screws (106) holding the inlet (102) and/or outlet (103) manifold to the covers (101).
2. Reverse the manifold and reattach. Install the screws and torque to 14–17 N•m on aluminum pumps. Torque to 22–25 N•m on cast iron and stainless steel pumps. See **Torque Sequence**, page 29.

<b>KEY</b>	101 Covers
N 1/2 npt(f) Air Inlet Port	102 Fluid Inlet Manifold
P Muffler; Air Exhaust Port is 3/4 npt(f)	103 Fluid Outlet Manifold
R* 2 in. bspt Fluid Inlet Port	106 Manifold and Cover Screws
S* 2 in. bspt Fluid Outlet Port	112 Cover Screws (Top and Bottom)

1 Torque to 14-17 N•m on Aluminum pumps. Torque to 22-25 Nom on cast iron and stainless steel pumps. See **Torque Sequence**, page 29

2 Torque to 22-25 N•m.

**Aluminum Model Shown**




FIG. 3

## Fluid Pressure Relief Valve

### ⚠ Caution

Some systems may require installation of a pressure relief valve at the pump outlet to prevent overpressurization and rupture of the pump or hose. See FIG. 4.

Thermal expansion of fluid in the outlet line can cause overpressurization. This can occur when using long fluid lines exposed to sunlight or ambient heat, or when pumping from a cool to a warm area (for example, from an underground tank).

Overpressurization can also occur if the *VERDERAIR* pump is being used to feed fluid to a piston pump, and the intake valve of the piston pump does not close, causing fluid to back up in the outlet line.

<b>KEY</b>	R* 2 in. bspt Fluid Inlet Port
S* 2 in. bspt Fluid Outlet Port	V Pressure Relief Valve Part No. 819.0159 (Stainless Steel)

1 Install valve between fluid inlet and outlet ports

2 Connect fluid inlet line here

3 Connect fluid outlet line here




FIG. 4

\* On pumps with connection Code 8=TB=bspt, connection Code 8=TN=npt, and connection Code 8=FC=Flange Center.

## Installation

### Air Exhaust Ventilation

#### Warning

#### **FIRE AND EXPLOSION HAZARD; HAZARDOUS FLUIDS**



Be sure to read and follow the warnings and precautions regarding **HAZARDOUS FLUIDS**, and **FIRE OR EXPLOSION HAZARD** on page 5, before operating this pump.



Be sure the system is properly ventilated for your type of installation. You must vent the exhaust to a safe place, away from people, animals, food handling areas, and all sources of ignition when pumping flammable or hazardous fluids.

Diaphragm failure will cause the fluid being pumped to exhaust with the air. Place an appropriate container at the end of the air exhaust line to catch the fluid. See FIG. 5.


The air exhaust port is 3/4 npt(f). Do not restrict the air exhaust port. Excessive exhaust restriction can cause erratic pump operation.

If the muffler (P) is installed directly to the air exhaust port, apply PTFE thread tape or anti-seize thread lubricant to the muffler threads before assembly.

To provide a remote exhaust:

1. Remove the muffler (P) from the pump air exhaust port.
2. Install a grounded air exhaust hose (T) and connect the muffler (P) to the other end of the hose. The minimum size for the air exhaust hose is 19 mm ID. If a hose longer than 4.57 m is required, use a larger diameter hose. Avoid sharp bends or kinks in the hose. See FIG. 5.
3. Place a container (U) at the end of the air exhaust line to catch fluid in case a diaphragm ruptures.

#### VENTING EXHAUST AIR



03942

FIG. 5

# Operation

## Flush the Pump Before First Use

The pump was tested in water. If water could contaminate the fluid you are pumping, flush it thoroughly with a compatible solvent. Follow the steps under **Starting and Adjusting the Pump**.

## Starting and Adjusting the Pump

### Warning



#### HAZARDOUS FLUIDS

To reduce the risk of serious injury, splashing in the eyes or on the skin, and toxic fluid spills, **never** move or lift a pump under pressure. If dropped, the fluid section may rupture. Always follow the **Pressure Relief Procedure Warning** at right before moving or lifting the pump.

1. Be sure the pump is properly grounded. Refer to **Grounding** on page 6.
2. Check all fittings to be sure they are tight. Be sure to use a compatible liquid thread sealant on all male threads. Tighten the fluid inlet and outlet fittings securely.
3. Place the suction tube (if used) in the fluid to be pumped.

**NOTE:** If the fluid inlet pressure to the pump is more than 25% of the outlet working pressure, the ball check valves will not close fast enough, resulting in inefficient pump operation.

4. Place the end of the fluid hose (L) into an appropriate container.
5. Close the fluid drain valve (J). See FIG. 2.
6. With the pump air regulator (C) closed, open all bleedtype master air valves (B, E).
7. If the fluid hose has a dispensing device, hold it open while continuing with the following step.
8. Slowly open the air regulator (C) until the pump starts to cycle. Allow the pump to cycle slowly until all air is pushed out of the lines and the pump is primed.

*If you are flushing*, run the pump long enough to thoroughly clean the pump and hoses. Close the air regulator. Remove the suction tube from the solvent and place it in the fluid to be pumped.

## Pump Shutdown

At the end of the work shift and before checking, adjusting, cleaning or repairing the system, follow the **Pressure Relief Procedure Warning** below.

## Pressure Relief Procedure

### Warning

To reduce the risk of serious injury, including splashing fluid in the eyes or on the skin, follow this procedure when this manual instructs you to relieve pressure, when you shut off the pump, and before checking, adjusting, cleaning, moving, or repairing any system equipment.

1. Shut off the air to the pump.
2. Open the dispensing valve, if used.
3. Open the fluid drain valve to relieve all fluid pressure, having a container ready to catch the drainage.

## Maintenance

### Lubrication

The air valve is designed to operate unlubricated, however if lubrication is desired, every 500 hours of operation (or monthly) remove the hose from the pump air inlet and add two drops of machine oil to the air inlet.

 **Caution**

Do not over-lubricate the pump. Oil is exhausted through the muffler, which could contaminate your fluid supply or other equipment. Excessive lubrication can also cause the pump to malfunction.

### Flushing and Storage

Flush the pump often enough to prevent the fluid you are pumping from drying or freezing in the pump and damaging it. Always flush the pump and follow the **Pressure Relief Procedure Warning** on page 11 before storing it for any length of time. Use a compatible solvent.

### Tightening Threaded Connections

Before each use, check all hoses for wear or damage, and replace as necessary. Check to be sure all threaded connections are tight and leak-free. Check fasteners. Tighten or retorquing as necessary. Although pump use varies, a general guideline is to retorquing fasteners every two months. See **Torque Sequence**, page 29.

### Preventive Maintenance Schedule

Establish a preventive maintenance schedule, based on the pump's service history. This is especially important for prevention of spills or leakage due to diaphragm failure.

# Troubleshooting

## Warning

To reduce the risk of serious injury, including splashing fluid in the eyes or on the skin, follow the **Pressure Relief Procedure** on page 11 when this manual instructs you to relieve pressure, when you shut off the pump, and before checking, adjusting, cleaning, moving, or repairing any system equipment.

**NOTE: Check all possible problems and causes before disassembling the pump.**

PROBLEM	CAUSE	SOLUTION
Pump cycles at stall or fails to hold pressure at stall.	Worn check valve balls (301), seats (201) or o-rings (202).	Replace. See page 16.
Pump will not cycle, or cycles once and stops.	Air valve is stuck or dirty.	Disassemble and clean air valve. See pages 14–15. Use filtered air.
	Check valve ball (301) severely worn and wedged in seat (201) or manifold (102 or 103).	Replace ball and seat. See page 16.
	Check valve ball (301) is wedged into seat (201), due to overpressurization.	Install Pressure Relief Valve (see page 9).
Pump operates erratically.	Dispensing valve clogged.	Relieve pressure and clear valve.
	Clogged suction line.	Inspect; clear.
	Sticky or leaking check valve balls (301).	Clean or replace. See page 16.
Air bubbles in fluid.	Diaphragm ruptured.	Replace. See pages 17–20.
	Restricted exhaust.	Remove restriction.
	Suction line is loose.	Tighten.
	Loose inlet manifold (102), damaged seal between manifold and seat (201), or damaged o-rings (202).	Tighten manifold bolts (106) or replace seats (201) or o-rings (202). See page 16.
	Loose diaphragm shaft bolt (107).	Tighten or replace. See pages 17–20.
Fluid in exhaust air.	Damaged o-ring (108).	Replace. See pages 17–20.
	Diaphragm ruptured.	Replace. See pages 17–20.
	Loose diaphragm shaft bolt (107).	Tighten or replace. See pages 17–20.
Pump exhausts excessive air at stall.	Damaged o-ring (108).	Replace. See pages 17–20.
	Worn air valve block (7†), o-ring (6†), plate (8), pilot block (18†), u-cups (10†), or pilot pin o-rings (17†).	Repair or replace. See pages 14–15.
Pump leaks air externally.	Worn shaft seals (402).	Replace. See pages 17–20.
	Air valve cover (2) or air valve cover screws (3) are loose.	Tighten screws. See page 15.
	Air valve gasket (4†) or air cover gasket (22) is damaged.	Inspect; replace. See pages 14–15, 21–22.
Pump leaks fluid externally from ball check valves.	Air cover screws (3) are loose.	Tighten screws. See pages 21–22.
	Loose manifolds (102, 103), damaged seal between manifold and seat (201), or damaged o-rings (202).	Tighten manifold bolts (106) or replace seats (201) or o-rings (202). See page 16.

## Service

### Repairing the Air Valve


#### Tools Required

- Torque wrench
- Torx (T20) screwdriver or 7 mm socket wrench
- Needle-nose pliers
- O-ring pick
- Lithium-base grease

**NOTE:** Air Valve Repair Kits 819.4274 (aluminum center housing models) and 819.0249 (sst center housing models) are available. Refer to page 23. Parts included in the kit are marked with a symbol, for example (3). Use all the parts in the kit for the best results.

#### Disassembly

1. Follow the **Pressure Relief Procedure Warning** on page 11.
2. With a Torx (T20) screwdriver or 7 mm socket wrench, remove the six screws (3), air valve cover (2), and gasket (4). See FIG. 6.
3. Move the valve carriage (5) to the center position and pull it out of the cavity. Remove the valve block (7†■) and o-ring (6†■) from the carriage. Using a needle-nose pliers, pull the pilot block (18†■) straight up and out of the cavity. See FIG. 7.
4. Pull the two actuator pistons (11) out of the bearings (12). Remove the u-cup packings (10†■) from the pistons. Pull the pilot pins (16) out of the bearings (15). Remove the o-rings (17†■) from the pilot pins. See FIG. 8.
5. Inspect the valve plate (8■) in place. If damaged, use a Torx (T20) screwdriver or 7 mm socket wrench to remove the three screws (3). Remove the valve plate (8■) and, on aluminum center housing models, remove the seal (9). See FIG. 9.
6. Inspect the bearings (12, 15) in place. See FIG. 8. The bearings are tapered and, if damaged, must be removed from the outside. This requires disassembly of the fluid section. See page 21.
7. Clean all parts and inspect for wear or damage. Replace as needed. Reassemble as explained on page 15.



2 Torque to 5.6–6.8 N•m.



03944B

FIG. 6

1 See Detail at right.

2 Grease.

3 Grease lower face.




03945B

FIG. 7

Service


- 1 Insert narrow end first.
- 2 Grease.
- 3 Install with lips facing narrow end of piston (11).
- 4 Insert wide end first.



03946B

FIG. 8

- 1 Rounded side must face down (aluminum center housing models only).
- 2 Tighten screws until they bottom out on the housing.



03947

FIG. 9

Reassembly

1. If you removed the bearings (12, 15), install new ones as explained on page 21. Reassemble the fluid section.
2. On aluminum center housing models, install the valve plate seal (9†) into the groove at the bottom of the valve cavity. The rounded side of the seal **must face down** into the groove. See FIG. 9.
3. Install the valve plate (8■) in the cavity. On aluminum center housing models, the plate is reversible, so either side can face up. Install the three screws (3), using a Torx (T20) screwdriver or 7 mm socket wrench. Tighten until the screws bottom out on the housing. See FIG. 9.
4. Install an o-ring (17†■) on each pilot pin (16). Grease the pins and o-rings. Insert the pins into the bearings (15), **narrow** end first. See FIG. 8.
5. Install a u-cup packing (10†■) on each actuator piston (11), so the lips of the packings face the **narrow** end of the pistons. See FIG. 8.
6. Lubricate the u-cup packings (10†■) and actuator piston (11). Insert the actuator pistons in the bearings (12), **wide** end first. Leave the narrow end of the pistons exposed. See FIG. 8.
7. Grease the lower face of the pilot block (18†■) and install so its tabs snap into the grooves on the ends of the pilot pins (16). See FIG. 7.
8. Grease the o-ring (6†■) and install it in the valve block (7†■). Push the block onto the valve carriage (5). Grease the lower face of the valve block. See FIG. 7.
9. Install the valve carriage (5) so its tabs slip into the grooves on the narrow end of the actuator pistons (11). See FIG. 7.
10. Align the valve gasket (4†■) and cover (2) with the six holes in the center housing (1). Secure with six screws (3), using a Torx (T20) screwdriver or 7 mm socket wrench. Torque to 5.6–6.8 N•m. See FIG. 6.

## Service

### Ball Check Valve Repair

#### Tools Required

- Torque wrench
- 10 mm socket wrench
- O-ring pick

#### Disassembly

**NOTE:** A Fluid Section Repair Kit is available. Refer to page 24 to order the correct kit for your pump. Parts included in the kit are marked with an asterisk, for example (201\*). Use all the parts in the kit for the best results.

**NOTE:** To ensure proper seating of the balls (301), always replace the seats (201) when replacing the balls.

**NOTE:** (Extension Version) To ensure proper sealing of extension (115), always replace o-rings (116) when replacing balls.

1. Follow the **Pressure Relief Procedure Warning** on page 11. Disconnect all hoses.
2. Remove the pump from its mounting.
3. Using a 10 mm socket wrench, remove the four bolts (106) holding the outlet manifold (103) to the fluid covers (101). See FIG. 10.
4. Remove the seats (201), balls (301), and o-rings (202) from the manifold.


**NOTE:** Some models do not use o-rings (202).

5. Turn the pump over and remove the inlet manifold (102). Remove the seats (201), balls (301), and o-rings (202) from the fluid covers (101).

#### Reassembly

1. Clean all parts and inspect for wear or damage. Replace parts as needed.
2. Reassemble in the reverse order, following all notes in Fig. 10. Be sure the ball checks are assembled **exactly** as shown. The arrows (A) on the fluid covers (101) **must** point toward the outlet manifold (103).

1. Apply medium-strength (blue) Loctite or equivalent to the threads. Torque to 14–17 Nm on aluminum pumps. Torque to 22–25 N•m on cast iron and stainless steel pumps. See **Torque Sequence** on page 29.
2. Arrow (A) must point toward outlet manifold (103).
3. Not used on some models.
4. Beveled seating surface must face ball (301).
5. Used on stainless steel model only.





# Service

## Diaphragm Repair


### Tools Required

- Torque wrench
- 10 mm socket wrench
- 13 mm socket wrench
- 15 mm socket wrench (aluminum models) or 1 in. socket wrench (stainless steel models)
- 19 mm open-end wrench
- O-ring pick
- Lithium-base grease

### Disassembly

**NOTE:** A Fluid Section Repair Kit is available. Refer to page 23 to order the correct kit for your pump. Parts included in the kit are marked with an asterisk, for example (401\*). Use all the parts in the kit for the best results.

1. Follow the **Pressure Relief Procedure Warning** on page 11.
2. Remove the manifolds and disassemble the ball check valves as explained on page 16.
3. Using 10 and 13 mm socket wrenches, remove the screws (106 and 112) holding the fluid covers (101) to the air covers (23). Pull the fluid covers (101) off the pump. See FIG. 11.



03949B

FIG. 11

## Service

4. Loosen but do not remove the diaphragm shaft bolts (107), using a 15 mm socket wrench (1 in. on stainless steel models) on both bolts.
5. Unscrew one bolt from the diaphragm shaft (24) and remove the o-ring (108), fluid side diaphragm plate (105), PTFE diaphragm (403, *used on PTFE Models only*), diaphragm (401), and air side diaphragm plate (104). See FIG. 12.

*For overmolded diaphragms:* Grip both diaphragms securely around the outer edge and rotate counterclockwise. One diaphragm assembly will come free and the other will remain attached to the shaft. Remove the freed diaphragm and air side plate.

6. Pull the other diaphragm assembly and the diaphragm shaft (24) out of the center housing (1). Hold the shaft flats with a 19 mm open-end wrench, and remove the bolt (107) from the shaft. Disassemble the remaining diaphragm assembly.

*For overmolded diaphragms:* Pull the other diaphragm assembly and the diaphragm shaft (24) out of the center housing (1). Hold the shaft flats with a 19 mm open-end wrench and remove the diaphragm and air side plate from the shaft.

7. Inspect the diaphragm shaft (24) for wear or scratches. If it is damaged, inspect the bearings (19) in place. If the bearings are damaged, refer to page 21.
8. Reach into the center housing (1) with an o-ring pick and hook the u-cup packings (402), then pull them out of the housing. This can be done with the bearings (19) in place.
9. Clean all parts and inspect for wear or damage. Replace parts as needed.

### Reassembly – Standard Diaphragms

1. Install the shaft u-cup packings (402\*) so the lips face **out** of the housing (1). Lubricate the packings. See FIG. 12.
2. Install the diaphragm assembly on one end of the shaft (24) as follows:
  - a. Install the o-ring (108\*) on the shaft bolt (107).
  - b. Install the fluid side diaphragm plate (105) on the bolt so the rounded side faces in, toward the diaphragm (401).

- c. *On PTFE Models only*, install the PTFE diaphragm (403\*). Make certain the side marked AIR SIDE faces the center housing (1).
  - d. Install the diaphragm (401\*) on the bolt. Make certain the side marked AIR SIDE faces the center housing (1).
  - e. Install the air side diaphragm plate (104) so the recessed side faces the diaphragm (401).
  - f. Apply medium-strength (blue) Loctite or equivalent to the bolt (107) threads. Screw the bolt (107) into the shaft (24) hand tight.
3. Grease the length and ends of the diaphragm shaft (24), and slide it through the housing (1).
  4. Assemble the other diaphragm assembly to the shaft as explained in step 2.
  5. Hold one shaft bolt (107) with a wrench and torque the other bolt to 27–34 N•m at 100 rpm maximum.
  6. Align the fluid covers (101) and the center housing (1) so the arrows (A) on the covers face the same direction as the air valve (B). Secure the covers with the screws (106 and 112), handtight. Install the longer screws (112) in the top and bottom holes of the covers. See FIG. 11.
  7. First, torque the longer screws (112) oppositely and evenly to 22–25 N•m, using a 13 mm socket wrench. Then torque the shorter screws (106), using a 10 mm socket wrench. See **Torque Sequence** on page 29.
  8. Reassemble the ball check valves and manifolds as explained on page 16.

## Reassembly – Overmolded Diaphragms

### WARNING

To reduce the risk of serious injury, including amputation, do not put your fingers or hand between the air cover and the diaphragm.

1. Lubricate and install the shaft u-cup packings (402\*) so the lips face **out** of the housing (1). See FIG. 13.
2. Assemble the air side plate (104) onto the diaphragm (401). The wide, radiused side of the plate must face the diaphragm. Apply medium-strength (blue) Loctite or equivalent to the threads of the diaphragm assembly. Screw the assembly into the shaft (24) hand-tight.
3. Grease the length and ends of the diaphragm shaft (24). Insert the shaft/diaphragm assembly into one side of the pump. Align the fluid cover (101) and the center housing (1) so the arrow (A) faces the same direction as the air valve. Secure the cover with the screws (106 and 112), handtight.
4. Torque the longer screws (112) oppositely and evenly to 22–25 Nm, using a 13mm socket wrench. Then torque the shorter screws (106), using a 10mm socket wrench. See **Torque Sequence** on page 29.

5. Assemble the other diaphragm assembly to the shaft as explained in step 2. This diaphragm will be lifted off the air cover at this point.
6. Supply the pump with low pressure air (less than 7 psi [0.05 MPa, 0.5 bar]). The diaphragm will very slowly pull onto the air cover. Find the pressure that keeps the diaphragm close enough to secure with the screws, but does not let it contact the pilot pin.


**NOTE:** Do not deform the diaphragm manually. The diaphragm needs uniform pressure to deform properly for maximum life.

7. Align the fluid cover (101) and the center housing (1) so the arrow (A) faces the same direction as the air valve. Secure the cover with two of the longer screws (112), handtight.

**NOTE:** If the diaphragm contacts the pilot pin and is forced away from the air cover, try Step 5 again. If necessary, return to Step 3.


8. Torque the longer screws (112) oppositely and evenly to 22–25 N•m, using a 13mm socket wrench. Then torque the shorter screws (106), using a 10mm socket wrench. See **Torque Sequence** on page 29.
9. Reassemble the ball check valves and manifolds as explained on page 16.

## Service




03981

**Cutaway View, with Diaphragms in Place**



03982

**Cutaway View, with Diaphragms Removed**



03950B

**FIG. 12**

## Service

### Bearing and Air Gasket Removal

#### Tools Required

- Torque wrench
- 10 mm socket wrench
- Bearing puller
- O-ring pick
- Press, or block and mallet

#### Disassembly

**NOTE:** Do not remove undamaged bearings.

1. Follow the **Pressure Relief Procedure** on page 11.
2. Remove the manifolds and disassemble the ball check valves as explained on page 16.
3. Remove the fluid covers and diaphragm assemblies as explained on page 17.

**NOTE:** If you are removing only the diaphragm shaft bearing (19), skip step 4.

4. Disassemble the air valve as explained on page 14.
5. Using a 10 mm socket wrench, remove the screws (25) holding the air covers (23) to the center housing (1). See FIG. 13.
6. Remove the air cover gaskets (22). Always replace the gaskets with new ones.


7. Use a bearing puller to remove the diaphragm shaft bearings (19), air valve bearings (12) or pilot pin bearings (15). Do not remove undamaged bearings.
8. If you removed the diaphragm shaft bearings (19), reach into the center housing (1) with an o-ring pick and hook the u-cup packings (402), then pull them out of the housing. Inspect the packings. See FIG. 12.

#### Reassembly

1. If removed, install the shaft u-cup packings (402\*) so the lips face **out** of the housing (1).
2. The bearings (19, 12, and 15) are tapered and can only be installed one way. Insert the bearings into the center housing (1), **tapered end first**. Using a press or a block and rubber mallet, press-fit the bearing so it is flush with the surface of the center housing.
3. Reassemble the air valve as explained on page 15.
4. Align the new air cover gasket (22) so the pilot pin (16) protruding from the center housing (1) fits through the proper hole (H) in the gasket.
5. Align the air cover (23) so the pilot pin (16) fits in the middle hole (M) of the three small holes near the center of the cover. Install the screws (25), handtight. See Fig. 13. Using a 10 mm socket wrench, torque the screws oppositely and evenly to 14–17 N•m.
6. Install the diaphragm assemblies and fluid covers as explained on page 17.
7. Reassemble the ball check valves and manifolds as explained on page 16.

## Service

- 1 Insert bearings tapered end first.
- 2 Press-fit bearings flush with surface of center housing (1).
- 3 Apply medium-strength (blue) Loctite or equivalent to the threads Torque to 14–17 N•m.



03951

03952B

FIG. 13

# Repair Kit Listing

## For **VERDERAIR VA 50** Aluminum, Stainless Steel, and Cast Iron Pumps, Series B

Repair Kits may only be ordered as kits. To repair the air valve, order **Part No. 819.4274** for aluminum center housing models or **Part No. 819.0249** for stainless steel center housing models (see page 25). Parts included in the Air Valve Repair Kit are marked with a symbol in the parts list, for example (3†). The list of existing Repair Kits is below:

Part No.	Seats	Balls	Diaphragms	O-Rings
819.0067	SS	GE	--	TF
819.2530	SV	VT	VT	VT
819.2531	SV	BN	BN	VT
819.2532	PP	BN	BN	TF
819.2533	BN	--	--	--
819.2534	--	BN	--	--
819.2535	--	--	BN	--
819.2536	SS	TF	TF	TF
819.2537	SS	TF	HY	TF
819.2538	SS	TF	SP	TF
819.2539	SS	TF	VT	TF
819.2540	SS	AC	TF	TF
819.2541	SS	AC	HY	TF
819.2543	SS	AC	VT	TF
819.2544	SS	HS	TF	TF
819.2545	SS	HS	HY	TF
819.2546	SS	HS	SP	TF
819.2547	SS	HS	VT	TF
819.2549	SS	HY	HY	TF
819.2550	SS	HY	SP	TF
819.2554	SS	SP	SP	TF
819.2555	SS	SP	VT	TF
819.2556	SS	VT	TF	TF
819.2559	SS	VT	VT	TF
819.2560	HS	TF	TF	TF
819.2562	HS	TF	SP	TF
819.2568	HS	HS	TF	TF
819.2569	HS	HS	HY	TF
819.2570	HS	HS	SP	TF
819.2571	HS	HS	VT	TF
819.2573	HS	HY	HY	TF
819.2578	HS	SP	SP	TF
819.2583	HS	VT	VT	TF
819.2584	HY	TF	TF	--
819.2585	HY	TF	HY	--
819.2588	HY	AC	TF	--
819.2589	HY	AC	HY	--
819.2592	HY	HS	TF	--
819.2593	HY	HS	HY	--
819.2594	HY	HS	SP	--
819.2595	HY	HS	VT	--
819.2596	HY	HY	TF	--
819.2597	HY	HY	HY	--
819.2601	HY	SP	HY	--
819.2603	HY	SP	VT	--

Part No.	Seats	Balls	Diaphragms	O-Rings
819.2605	HY	VT	HY	--
819.2607	HY	VT	VT	--
819.2608	SP	TF	TF	TF
819.2610	SP	TF	SP	TF
819.2616	SP	HS	TF	TF
819.2617	SP	HS	HY	TF
819.2618	SP	HS	SP	TF
819.2619	SP	HS	VT	TF
819.2621	SP	HY	HY	TF
819.2622	SP	HY	SP	TF
819.2624	SP	SP	TF	TF
819.2625	SP	SP	HY	TF
819.2626	SP	SP	SP	TF
819.2631	SP	VT	VT	TF
819.2632	VT	TF	TF	--
819.2650	VT	SP	SP	--
819.2655	VT	VT	VT	--
819.2656	PP	TF	TF	TF
819.2659	PP	TF	VT	TF
819.2660	PP	AC	TF	TF
819.2661	PP	AC	HY	TF
819.2662	PP	AC	SP	TF
819.2664	PP	HS	TF	TF
819.2665	PP	HS	HY	TF
819.2666	PP	HS	SP	TF
819.2667	PP	HS	VT	TF
819.2669	PP	HY	HY	TF
819.2674	PP	SP	SP	TF
819.2676	PP	VT	TF	TF
819.2679	PP	VT	VT	TF
819.2680	--	--	GE	--
819.2681	BN	BN	BN	--
819.2682	SS	BN	BN	TF
819.3804	SS	GE	GE	TF
819.3805	GE	GE	GE	TF
819.3809	PP	GE	GE	TF
819.6280	--	--	TF	--
819.6231	--	--	SP	--
819.6282	--	--	VT	--
819.6283	--	TF	--	--
819.6284	--	TF	TF	--
819.6287	--	SP	--	--
819.6288	--	SP	TF	--
819.6289	--	SP	SP	--
819.6291	--	VT	--	--
819.6294	--	VT	VT	--

Part No.	Seats	Balls	Diaphragms	O-Rings
819.6295	SS	-	--	TF
819.6296	SS	-	TF	TF
819.6297	SS	-	SP	TF
819.6299	SS	TF	--	TF
819.6300	SS	SP	--	TF
819.6301	SS	VT	--	TF
819.6302	SP	-	--	TF
819.6304	SP	-	SP	TF
819.6306	SP	TF	--	TF
819.6307	SP	SP	--	TF
819.6308	SP	VT	--	TF
819.6532	KY	TF	TF	TF
819.6535	KY	TF	VT	TF
819.6539	KY	AC	VT	TF
819.6540	KY	HS	TF	TF
819.6541	KY	HS	HY	TF
819.6542	KY	HS	SP	TF
819.6543	KY	HS	VT	TF
819.6555	KY	VT	VT	TF
819.6874	HY	AC	--	--
819.6876	--	-	HY	--
819.9731	GE	HS	GE	TF
819.1323	SS	TF	TO	TF
819.1322	SS	SP	TF	TF
819.6279	--	-	--	--
819.6534	KY	TF	SP	TF
819.1358	GE	-	--	TF
819.1359	HS	-	--	TF
819.1360	HY	-	--	--
819.1362	PP	-	--	TF
819.1363	VT	-	--	--
819.1364	--	AC	--	--
819.1365	--	GE	--	--
819.1366	--	HS	--	--
819.1367	--	HY	--	--
819.1368	--	-	TO	--

AC = Acetal HY = TPE SS = 316 sst TF = PTFE  
 KY = PVDF VT = FKM SP = Santoprene  
 HS = 440C (hardened) sst PP = Polypropylene  
 GE = Geolast -- = NULL

### Overmolded PTFE Diaphragm Kits

819.0397 – VA 50 HD Overmolded PTFE repair kit  
 819.0398 – VA 50 HD Overmolded PTFE repair kit with new air–side diaphragm plates


**NOTE:** Heavy–duty overmolded diaphragms require new air–side diaphragm plates. If a bolt–through diaphragm was in use, you must purchase 819.0398, the kit that includes the new plates.

### Diaphragm Set VA 50 Plate Kit



819.0336 – Diaphragm set VA 50 plate kit



# Parts



**Aluminum Model Shown**



T10354C

1 Not used on some models

2 Used on stainless steel model only

\* These parts are included in the Pump Repair Kit, which may only be purchased as a kit. Refer to the Repair Kit Listing on page 23 to determine the correct kit for your pump.

† These parts are included in Air Valve Repair Kit 819.4274 (aluminum center housing models), which may only be purchased as a kit.

■ These parts are included in Air Valve Repair Kit 819.0249 (sst center housing models) which may only be purchased as a kit.

▲ Replacement Danger and Warning labels, tags and cards are available at no cost.

‡ These parts are used on extension version only. Ref. No. 106 will be qty. 20 on extension version.

## Parts

### Air Motor Parts List

Ref. No.	Part No.	Description	Qty
1	819.4275	HOUSING, center; aluminum	1
	819.0247	HOUSING, center; stainless steel	1
2	819.4276	COVER, air valve; aluminum	1
	819.0259	COVER, air valve; stainless steel	1
3	819.0221	SCREW, mach, hex flange hd; M5 x 0.8; 12 mm	9
4†■	819.4278	GASKET, cover; Santoprene®	1
5	819.4279	CARRIAGE; aluminum	1
6†■	819.4280	O-RING; nitrile	1
7†■	819.4281	BLOCK, air valve; acetal	1
8■	Alum. 819.4282	PLATE, air valve; sst	1
	SST 819.0248	PLATE, air valve; sst	1
9†	Alum. 819.4283	SEAL, valve plate; buna-N	1
	SST -	-	-
10†■	819.4284	PACKING, u-cup; nitrile	2
11	819.4285	PISTON, actuator; acetal	2
12	819.4286	BEARING, piston; acetal	2
15	819.4287	BEARING, pin; acetal	2
16	819.4288	PIN, pilot; stainless steel	2
17†■	819.4289	O-RING; buna-N	2
18†■	819.4290	BLOCK, pilot; acetal	1
19	819.4291	BEARING, shaft; acetal	2
20	819.0220	SCREW, grounding	1
22	819.4294	GASKET, air cover; foam	2
23	819.4295	COVER, air; aluminum	2
	819.7110	COVER, air; stainless steel	2
24	819.4296	SHAFT, diaphragm; sst	1
25	819.7051	SCREW; M8 x 1.25; 25 mm	12

### Fluid Section Parts List

Fluid Section Material (Code 3)	Ref. No.	Part No.	Description	Qty
	101	819.0223	COVER, fluid; aluminum	2
	102	819.6979	MANIFOLD, inlet; aluminum, bspt (Code 8=TB)	1
		819.4299	MANIFOLD, inlet aluminum, npt (Code 8=TN)	
	103	819.0225	MANIFOLD, outlet; aluminum, bspt (Code 8=TB)	1
		819.0224	MANIFOLD, outlet aluminum, npt (Code 8=TN)	
	104	Standard Diaphragms 819.4301	PLATE, air side; aluminum	2
		OM Diaphragms Air plate not sold separately	PLATE, air side	2
A	105*	Standard Diaphragms 819.0336	PLATE, fluid side; zinc plated carbon steel	2
		OM Diaphragms -	-	-
	106	819.7052	SCREW; M10 x 1.50; 35 mm	24 or 20/
	107	819.4312	BOLT; M12 x 1.75; 55 mm; 316 stainless steel	2
	108*	819.4304	O-RING; PTFE	2
	110▲	819.6310	LABEL, warning	1
	111	819.7000	MUFFLER	1
	112	819.7053	SCREW; M10 x 1.50; 90 mm	8
	115‡	819.9754	EXTENSION, 2150	2
	116‡	819.0238	PACKING, o-ring	2
	117‡	819.4307	SCREW, mach, hex	4

**Fluid Section Parts List continued**

Fluid Section Material (Code 3)	Ref. No.	Part No.	Description	Qty
<b>S</b>	101	819.7015	COVER, fluid; 316 stainless steel	2
	102	819.7012	MANIFOLD, inlet; 316 stainless steel, bspt (Code 8= <b>TB</b> )	1
		819.7098	MANIFOLD, inlet; 316 stainless steel, NPT (Code 8= <b>TN</b> )	
		819.1334	MANIFOLD, inlet; stainless steel center flange (Code 8= <b>FC</b> )	
	103	819.7013	MANIFOLD, outlet; 316 stainless steel, bspt (Code 8= <b>TB</b> )	1
		819.7099	MANIFOLD, outlet; 316 stainless steel NPT (Code 8= <b>TN</b> )	
		819.1335	MANIFOLD, outlet; stainless steel center flange (Code 8= <b>FC</b> )	
	104	819.4301	PLATE, air side; aluminum	2
	105	819.4311	PLATE, fluid side; 316 stainless steel	2
	106	819.4343	SCREW; M10 x 1.38; 35 mm	24
	107	819.4312	BOLT; M12 x 1.75; 55 mm; 316 stainless steel	2
	108*	819.4304	O-RING; PTFE	2
	110▲	819.4313	LABEL, warning	1
	111	819.7000	MUFFLER	1
	112	819.4314	SCREW; M10 x 1.50; 110 mm; stainless steel	8
			NUT; M10	8

Fluid Section Material (Code 3)	Ref. No.	Part No.	Description	Qty
<b>I</b>	101	819.6482	COVER, fluid; cast iron	2
	102	819.7100	MANIFOLD, inlet; cast iron, npt (Code 8= <b>TN</b> )	1
		819.6345	MANIFOLD, inlet; cast iron, bspt (Code 8= <b>TB</b> )	1
	103	819.7101	MANIFOLD, outlet; cast iron, npt (Code 8= <b>TN</b> )	1
		819.6483	MANIFOLD, outlet; cast iron, bspt (Code 8= <b>TB</b> )	1
	104	819.4301	PLATE, air side; aluminum,	2
	105*	819.0336	PLATE, fluid side; carbon steel	2
	106	819.4343	SCREW; M10 x 1.38; 35 mm	24
	107	819.4312	BOLT; M12 x 1.75; 55 mm; 316 stainless steel	2
	108*	819.4304	O-RING; PTFE	2
	110▲	819.4313	LABEL, warning	1
	111	819.7000	MUFFLER	1
112	819.4314	SCREW; M10 x 1.50; 110 mm; stainless steel	8	

## Parts

### Valve Seat Kits

Seat Material	Ref. No.	Kit No.	Description	Qty
BN	201	819.2533	VA50M BN,--,--,--	1
	202	Not required		
GE	201	819.1358	VA50M GE,--,--,TF	1
	202	Included in above kit		
HS	201	819.1359	VA50M HS,--,--,TF	1
	202	Included in above kit		
HY	201	819.1360	VA50M HY,--,--,--	1
	202	Not required		
PP	201	819.1362	VA50M PP,--,--,TF	1
	202	Included in above kit		
SP	201	819.6302	VA50M SP,--,--,TF	1
	202	Included in above kit		
SS	201	819.6295	VA50M SS,--,--,TF	1
	202	Included in above kit		
VT	201	819.1363	VA50M VT,--,--,--	1
	202	Not required		

### Diaphragm Kits

Diaphragm Material	Ref. No.	Kit No.	Description	Qty
BN	401	819.2535	VA50M --,--,BN,--	1
	402	Included in above kit		
GE	401	819.2680	VA50M --,--,GE,--	1
	402	Included in above kit		
HY	401	819.6876	VA50M --,--,HY,--	1
	402	Included in above kit		
SP	401	819.6281	VA50M --,--,SP,--	1
	402	Included in above kit		
TF	401	819.6280	VA50M --,--,TF,--	1
	402	Included in above kit		
	403	Included in above kit		
TO	401	819.1368	VA50M --,--,TO,--	1
	402	Included in above kit		
VT	401	819.6282	VA50M --,--,VT,--	1
	402	Included in above kit		

### Check Ball Kits


Ball Material	Ref. No.	Kit No.	Description	Qty
AC	301	819.1364	VA50M --,AC,--,--	1
BN	301	819.2534	VA50M --,BN,--,--	1
GE	301	819.1365	VA50M --,GE,--,--	1
HS	301	819.1366	VA50M --,HS,--,--	1
HY	301	819.1367	VA50M --,HY,--,--	1
SP	301	819.6287	VA50M --,SP,--,--	1
TF	301	819.6283	VA50M --,TF,--,--	1
VT	301	819.6291	VA50M --,VT,--,--	1

# Torque Sequence


Always follow torque sequence when instructed to torque fasteners.

## Aluminum Pumps


1. Left/Right Fluid Covers  
Torque bolts to 22–25 N•m



2. Inlet Manifold  
Torque bolts to 14–17 N•m




3. Outlet Manifold  
Torque bolts to 14–17 N•m




## Cast Iron and Stainless Steel Pumps


1. Left/Right Fluid Covers  
Torque bolts to 22–25 N•m



2. Inlet Manifold  
Torque bolts to 22–25 N•m




3. Outlet Manifold  
Torque bolts to 22–25 N•m




# Dimensions


**FRONT VIEW**



**PUMP MOUNTING HOLE PATTERN**



**SIDE VIEW**




Dimensions B, C, F, G, H and M can vary by up to 1/4 in. (6.3 mm) depending on the seat and diaphragm material fitted in the pump.


7440A

# Stainless Steel or Aluminum Pump with Center Flange

**FRONT VIEW**




**SIDE VIEW**



**PUMP MOUNTING HOLE PATTERN**

4X 0.56 in.  
(14.2 mm)



Dimensions B, C, F, G, H and M can vary by up to 1/4 in. (6.3 mm) depending on the seat and diaphragm material fitted in the pump.

ti36736a

## Dimensions

Dimension	Aluminum Center Aluminum Cover		Aluminum Center Aluminum Cover Extended Pump*		Aluminum Center SST Cover		Aluminum OR SST Center SST Cover Flanged Manifold Ports		Aluminum Center Cast Iron Cover		SST Center Aluminum Cover		SST Center SST Cover	
	in.	mm	in.	mm	in.	mm	in.	mm	in.	mm	in.	mm	in.	mm
B	9.0	229	9.1	231	9.4	238	8.7	221	9.7	245	9.0	229	9.4	238
C	12.9	328	12.9	328	15.2	385	17.2	437	12.9	327	12.9	328	15.2	385
D	6.0	152	6.0	152	6.5	165	6.5	165	6.0	152	6.0	152	6.5	165
E	17.5	443	17.4	442	18.1	459	18.1	459	18.5	469	17.5	443	18.1	459
F	19.9	506	22.9	581	22.3	565	22.3	565	19.3	491	19.9	506	22.3	565
G	21.9	557	24.9	632	24.9	631	26.8	681	21.3	542	21.9	557	24.8	629
H†	23.6	598	26.5	673	26.3	668	29.8/31.8	757/808	22.8	578	23.6	598	26.3	668
J	2.0	51	2.0	51	2.5	64	4.5	114	2.0	51	2.0	51	2.5	64
K	0.4	10	0.4	10	0.9	24	---	---	0.6	14	0.4	10	0.9	24
L	6.0	152	6.0	152	6.0	152	11.0	279	6.0	152	6.0	152	6.0	152
M	6.0	152	6.0	152	5.8	146	5.8	147	7.0	178	6.0	152	5.8	146

\*Aluminum extended pump matches the inlet to outlet dimensions of Wilden and Aro aluminum pumps. This will help for ease of installation during upgrades.

†Dimension H for flanged port manifolds represent both the horizontal and vertical outlet manifold port dimensions.



# Technical Data

Maximum Fluid Working Pressure .....	8.4 bar	
Air Pressure Operating Range .....	1.4–8.4 bar	
Maximum Air Consumption .....	4.9 N m <sup>3</sup> /min	
Air Consumption at 4,9 bar/ 227 l/min .....	1.68 N m <sup>3</sup> /min (see chart)	
Maximum Free Flow Delivery.....	568 l/min	
Maximum Pump Speed.....	145 cpm	
Liters per cycle .....	3.90	
Maximum Suction Lift.....	5.48 m wet or dry	
Maximum Size Pumpable Solids.....	6.3 mm	
* Sound Pressure Level at 7 bar, 50 cpm .....	90 dBA	
* Sound Power Level at 7 bar, 50 cpm.....	103 dBA	
* Sound Pressure Level at 4,9 bar, 50 cpm .....	85 dBA	
Maximum Operating Temperature .....	65.5C; 93.3°C for models with PTFE diaphragms	
Air Inlet Size.....	1/2 npt(f)	
† Fluid Inlet Size.....	2 in. bspt ANSI/DIN 50 Flange..... 2 in. (50 mm)	
† Fluid Outlet Size.....	2 in. bspt ANSI/DIN 50 Flange .....	2 in. (50 mm)

Wetted Parts .....	Vary by Model. See pages 25–28.
Non-wetted External Parts .....	Aluminum, 302, 316 Stainless Steel, Polyester (labels)
Weight.....	Aluminum Pumps: 26.3 kg Stainless Steel Pumps with aluminum air motors: 50.3 kg Stainless steel pumps with stainless steel air motors: 61.0 kg Cast Iron Pumps: 59.0 kg

Loctite® is a registered trademark of the Loctite Corporation.

Santoprene® is a registered trademark of the Monsanto Co.

‡ Startup pressure may vary based on environmental conditions.

\* Sound pressure levels measured with the pump mounted on the floor, using Rubber Foot Kit 819.4333 Sound power measured per ISO Standard 9614–2.

† Reference Code 8, connections: TB=bspt, TN=npt, FC=Flange Center.

## Fluid Temperature Range

**NOTICE**


Temperature limits are based on mechanical stress only. Certain chemicals will further limit the fluid temperature range. Stay within the temperature range of the most-restricted wetted component. Operating at a fluid temperature that is too high or too low for the components of your pump may cause equipment damage.

Diaphragm/Ball/Seat Material	Fluid Temperature Range					
	Aluminum, Hastelloy, or Stainless Steel Pumps		Polypropylene or Conductive Polypropylene Pumps		PVDF Pumps	
	Fahrenheit	Celsius	Fahrenheit	Celsius	Fahrenheit	Celsius
Acetal (AC)	10° to 180°F	-12° to 82°C	32° to 150°F	0° to 66°C	10° to 180°F	-12° to 82°C
Buna-N (BN)	10° to 180°F	-12° to 82°C	32° to 150°F	0° to 66°C	10° to 180°F	-12° to 82°C
FKM Fluoroelastomer (FK)*	-40° to 275°F	-40° to 135°C	32° to 150°F	0° to 66°C	10° to 225°F	-12° to 107°C
Geolast® (GE)	-40° to 150°F	-40° to 66°C	32° to 150°F	0° to 66°C	10° to 150°F	-12° to 66°C
Polychloroprene overmolded diaphragm (CO) or Polychloroprene check balls (CR or CW)	0° to 180°F	-18° to 82°C	32° to 150°F	0° to 66°C	10° to 180°F	-12° to 82°C
Polypropylene (PP)	32° to 150°F	0° to 66°C	32° to 150°F	0° to 66°C	32° to 150°F	0° to 66°C
PTFE overmolded diaphragm (PO)	40° to 180°F	4° to 82°C	40° to 150°F	4° to 66°C	40° to 180°F	4.0° to 82°C
PTFE check balls or two-piece PTFE/EPDM diaphragm (PT)	40° to 220°F	4° to 104°C	40° to 150°F	4° to 66°C	40° to 220°F	4° to 104°C
PVDF (PV)	10° to 225°F	-12° to 107°C	32° to 150°F	0° to 66°C	10° to 225°F	-12° to 107°C
Santoprene® (SP)	-40° to 180°F	-40° to 82°C	32° to 150°F	0° to 66°C	10° to 180°F	-12° to 82°C
TPE (TP)	-20° to 150°F	-29° to 66°C	32° to 150°F	0° to 66°C	10° to 150°F	-12° to 66°C

\* The maximum temperature listed is based on the ATEX standard for T4 temperature classification. If you are operating in a non-explosive environment, FKM fluoroelastomer's maximum fluid temperature in aluminum or stainless steel pumps is 320°F (160°C).

# Performance Chart

**Example of Finding Pump Air Consumption and Air Pressure at a Specific Fluid Delivery and Discharge Head:**  
 To supply 227 liters fluid flow (horizontal scale) at 2.8 bar discharge head pressure (vertical scale) requires approximately 1.68 N m<sup>3</sup>/min air consumption at 4.9 bar inlet air pressure.



**TEST CONDITIONS**  
 Pump tested in water with PTFE diaphragm and inlet submerged.

**KEY** ——— FLUID PRESSURE AND FLOW  
 ——— N m<sup>3</sup>/min AIR CONSUMPTION

---

# Customer Services/Guarantee

## CUSTOMER SERVICES

If you require spare parts, please contact your local distributor, providing the following details:

- Pump Model
- Type
- Serial Number, and
- Date of First Order.

## GUARANTEE

All VERDER pumps are warranted to the original user against defects in workmanship or materials under normal use (rental use excluded) for two years after purchase date. This warranty does not cover failure of parts or components due to normal wear, damage or failure which in the judgement of VERDER arises from misuse.

Parts determined by VERDER to be defective in material or workmanship will be repaired or replaced.

## LIMITATION OF LIABILITY

To the extent allowable under applicable law, VERDER's liability for consequential damages is expressly disclaimed. VERDER's liability in all events is limited and shall not exceed the purchase price.

## WARRANTY DISCLAIMER

VERDER has made an effort to illustrate and describe the products in the enclosed brochure accurately; however, such illustrations and descriptions are for the sole purpose of identification and do not express or imply a warranty that the products are merchantable, or fit for a particular purpose, or that the products will necessarily conform to the illustration or descriptions.

## PRODUCT SUITABILITY

Many regions, states and localities have codes and regulations governing the sale, construction, installation and/or use of products for certain purposes, which may vary from those in neighbouring areas. While VERDER attempts to assure that its products comply with such codes, it cannot guarantee compliance, and cannot be responsible for how the product is installed or used. Before purchasing and using a product, please review the product application as well as the national and local codes and regulations, and be sure that product, installation, and use complies with them.

Original instructions. This manual contains English.  
Revision ZAK, December 2019

**Austria**

Verder Austria  
Eitnergasse 21/Top 8  
A-1230 Wien  
AUSTRIA  
Tel: +43 1 86 51 074 0  
Fax: +43 1 86 51 076  
e-mail: office@verder.at

**Belgium**

Verder nv  
Kontichsesteenweg 17  
B-2630 Aartselaar  
BELGIUM  
Tel: +32 3 877 11 12  
Fax: +32 3 877 05 75  
e-mail: info@verder.be

**China**

Verder Shanghai Instruments and Equipment Co., Ltd  
Building 8 Fuhai Business Park No. 299  
Bisheng Road, Zhangjiang Hiteck Park  
Shanghai 201204  
CHINA  
Tel: +86 21 33932950  
Fax: +86 21 33932955  
e-mail: info@verder.cn

**Bulgaria**

Verder Bulgaria Ltd  
Vitosh department,  
Manastriski Livadi Zapad  
district,  
110 Bulgaria Blvd., 2-nd  
Floor, apt. 15-16,  
1618 - Sofia  
BULGARIA  
Tel: 0878407370  
Fax: 02 9584085  
email: office@verder.bg

**Czech Republic**

Verder s.r.o.  
Vodnanská 651/6 (vchod  
Chlumecka 15)  
198 00 Praha 9-Kyje  
CZECH REPUBLIC  
Tel: +420 261 225 386-7  
Web: http://www.verder.cz  
e-mail: info@verder.cz

**France**

Verder France  
8 Allée Rosa Luxembourg  
Immeulde Arizona  
95610 Eragny sur Oise  
FRANCE  
Tel: +33 173 43 98 41  
Fax: +33 134 64 44 50  
e-mail: info@verder.fr

**Germany**

Verder Deutschland GmbH  
Retsch-Allee 1-5  
42781 Haan  
GERMANY  
Tel: 02104/2333-200  
Fax: 02104/2333-299  
e-mail: info@verder.de

**Hungary**

Verder Hongary Kft  
Budafoke ut 187 - 189  
HU-1117 Budapest  
HUNGARY  
Tel: 0036 1 3651140  
Fax: 0036 1 3725232  
e-mail: info@verder.hu

**India**

Verder India Pumps Pvt  
Ltd.  
Plot No-3B, D-1 Block,  
MIDC Chinchwad,  
Pune - 411019  
INDIA  
e-mail:  
Sales@verder.co.in  
www.verder.co.in

**Italy**

Verder Italia  
Via Maestri Del lavoro, 5  
02100 Vazia, Rieti  
ITALY  
Tel: +39 07 46 229064  
e-mail: info@verder.it

**The Netherlands**

Verder BV  
Leningradweg 5  
NL 9723 TP Groningen  
THE NETHERLANDS  
Tel: +31 50 549 59 00  
Fax: +31 50 549 59 01  
e-mail: info@verder.nl

**Poland**

Verder Polska  
ul.Porcelanowa 23  
PL-40 036 Katowice  
POLAND  
Tel: +48 32 78 15 032  
Fax: +48 32 78 15 034  
e-mail: verder@verder.pl

**Romania**

Verder România  
Drumul Balta Doamnei  
no 57-61  
Sector 3  
CP 72-117  
032624 Bucuresti  
ROMANIA  
Tel: +40 21 335 45 92  
Fax: +40 21 337 33 92  
e-mail: office@verder.ro

**Slovak Republik**

Verder Slovakia s.r.o.  
Silacska 1  
SK-831 02 Bratislava  
SLOVAK REPUBLIK  
Tel: +421 2 4463 07 88  
Fax: +421 2 4445 65 78  
e-mail: info@verder.sk

**South Africa**

Verder SA  
197 Flaming Rock Avenue  
Northlands Business Park  
Newmarket Street  
ZA Northriding  
SOUTH AFRICA  
Tel: +27 11 704 7500  
Fax: +27 11 704 7515  
e-mail: info@verder.co.za

**Switzerland**

Verder Deutschland GmbH  
Sales Switzerland  
Retsch-Allee 1-5  
D-42781 Haan  
GERMANY  
Tel: +41 (0)61 331 33 13  
Fax: +41 (0)61 331 63 22  
e-mail: info@verder.ch

**United Kingdom**

Verder UK Ltd.  
Unit 3 California Drive  
Castleford, WF10 5QH  
UNITED KINGDOM  
Tel: +44 (0) 1924 221 001  
Fax: +44 (0) 1132 465 649  
e-mail: info@verder.co.uk

**United States of America**

Verder Inc.  
312 Corporate Parkway  
Suite 101  
Macon, GA 31210  
USA  
Tel: +1 877 783 7337  
Fax: +1 478 476 9867  
e-mail: sales@verder-  
us.com